MONOPOD V2 Manual

Package contents

The Bushman Monopod V2 includes a simple reliable kit for your 360 camera:



1) Counterweight 400g: is for the stability of the camera on the monopod. \mathcal{U}'' thread on both ends.

2) Bushman Monopod v2: open to a length of 154cm. ¼" thread on both ends.

3) Jade Tripod: is a 2 position tripod. Lower position is the one that we strongly recommend for stability. The upper position should not be used in the windy conditions. Please note that in the upper position it is not always horizontal.

How to work with the Bushman Monopod v2:

1) Bushman Monopod: With one hand grab all lock and turn them 1/3 of a turn to open them. Pull all sections of the pole to the length that you need. Then each lock turn 1/3 of a turn in the other direction to lock them in place.

2) Jade Tripod: The tripod has two possible positions. For stability we recommend using the lower position of the tripod. The top ring of the tripod can turn to lock or unlock the tripod legs. With time you might find that the tripod legs will get loose. They can be tightened with an Allen Wrench.



3) Assembling The classic way of assembling in: Tripod+CW+Monopod.

4) Extra Counterweight. Feel free to add extra counterweight if you want to increase the stability.

5) Camera: you can screw on your 360 cameras on the $\ensuremath{\ensuremath{\mathscr{Y}}}$ " thread on the top of the pole.